



PARTS MAP

Model: _____

Serial Number: _____

Notes:

Upper Casing Section


- 1 Factory Pre-Assembled Platforms with Perimeter Handrails
- 2 Drift Eliminators
- 3 BranchLok™ Removal System
 - A Feed Box Assembly
 - B Spray Branch
 - C Nozzles

- 4 Coil


Basin Section

- 5 Access Door with Safety Handle and Step
- 6 Internal Walkway
- 7 Fan Cover
- 8 Water Guards
- 9 Pump
- 10 Pump Riser Piping
- 11 Make-Up Valve Assembly
- 12 Float Ball
- 13 Strainer Assembly
- 14 EC Direct Drive Fan System Assembly
- 15 Terminal Box

VERTEX™ EVAPORATIVE CONDENSER



EC Direct Drive System



Reduce Downtime
Spare Parts List (page 2)

Recommended Spare Parts

BAC Factory Authorized Parts are manufactured to meet rigorous specifications and are guaranteed to fit your unit and perform as original equipment.

BAC Factory Authorized Parts can be ordered through your local BAC Representative. Most BAC Representatives maintain a local inventory of commonly used parts. For a free unit inspection and a specific parts list for your serial number, contact your local BAC Representative today.

Even with BAC's fast delivery capability, it is still recommended that certain essential and emergency repair part be maintained in your inventory to minimize any potential downtime.



Find my BAC Rep to order parts, get maintenance tips, and get a free unit inspection: www.baltimoreaircoil.com/RepFinder



Vertex™ Evaporative Condenser

EC Direct Drive System

Basic Recommended Spare Parts

Basin Heater & LWCO (if equipped)

Door Gaskets

Make-Up Valve Assembly & Float Ball

Spray Nozzles

Suction Strainer

Pump Seal Kit

Parts to Consider if Extended Downtime is a Concern

EC Direct Drive Fan System Assembly

Pump



Scan to locate
your local BAC
Representative



PARTS MAP

Model: _____

Serial Number: _____

Notes:

Upper Casing Section

- 1 Factory Pre-Assembled Platforms with Perimeter Handrails
- 2 Drift Eliminators
- 3 BranchLok™ Removal System
 - A Feed Box Assembly
 - B Spray Branch
 - C Nozzles
- 4 Coil

Basin Section

- 5 Access Door with Safety Handle and Step
- 6 Internal Walkway
- 7 Partition Doors
- 8 Pump
- 9 Pump Riser Piping
- 10 Make-Up Valve Assembly
- 11 Float Ball
- 12 Strainer Assembly
- 13 Air Intake Screens
- 14 Baltidrive® Power Train (see detailed view)

VERTEX™ EVAPORATIVE CONDENSER



Baltidrive® Power Train

Baltidrive® Power Train

- A Belt Set
- B Fan Sheave
- C Fan Sheave Bushing
- D Fan Bushing
- E Axial Fan Assembly
- F Fan Shaft
- G Bearing Kit
- H Mechanical Equipment Support
- I Fan Cowl Assembly
- J Motor
- K Motor Sheave
- L Motor Sheave Bushing
- M Motor Base and Adjustment Rod Kit Assembly

Reduce Downtime
Spare Parts List (page 2)

Recommended Spare Parts


BAC Factory Authorized Parts are manufactured to meet rigorous specifications and are guaranteed to fit your unit and perform as original equipment.

BAC Factory Authorized Parts can be ordered through your local BAC Representative. Most BAC Representatives maintain a local inventory of commonly used parts. For a free unit inspection and a specific parts list for your serial number, contact your local BAC Representative today.

Even with BAC's fast delivery capability, it is still recommended that certain essential and emergency repair part be maintained in your inventory to minimize any potential downtime.



Find my BAC Rep to order parts, get maintenance tips, and get a free unit inspection: www.baltimoreaircoil.com/RepFinder



Vertex™ Evaporative Condenser

Baltidrive® Power Train

Basic Recommended Spare Parts

Bearings

Bearing Greaser Refill Kit (if equipped)

Belts

Basin Heater & LWCO

Door Gaskets

Make-Up Valve Assembly & Float Ball

Solenoid Valve (if unit equipped with EWLC)

Spray Nozzles

Suction Strainer

Sheave and Bushing Sets

Pump Seal Kit

Parts to Consider if Extended Downtime is a Concern

Fan and Fan Bushing

Fan Shaft

Fan Motor

Pump



Scan to locate
your local BAC
Representative