



# PARTS MAP

Model: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Notes:

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

## Water Distribution

- 1 Slide Out Drift Eliminators
- 2 Removable Spray Distribution Branch
- 3 Spray Nozzles
- 4 hCore™ Heat Transfer Technology
- 5 Water Diverter

## Air Handling

- 6 Hinged EC Fan System Access Panel
- 7 EC Fan System
- 8 Fan Guard

## Water Collection

- 9 Spray Water Basin
- 10 Mechanical Make-up Assembly
- 11 Solenoid Make-up Valve
- 12 Drain Valve
- 13 Overflow
- 14 Spray Pump
- 15 High/Low Level Float Switch


## Controls

- 16 iPilot™ Control System (not pictured)



# NEXUS®

## MODULAR HYBRID COOLER



# Recommended Spare Parts

**BAC Factory Authorized Parts** are manufactured to meet rigorous specifications and are guaranteed to fit your unit and perform as original equipment.

BAC Factory Authorized Parts can be ordered through your local BAC Representative. Most BAC Representatives maintain a local inventory of commonly used parts. For a free unit inspection and a specific parts list for your serial number, contact your local BAC Representative today.

Even with BAC's fast delivery capability, it is still recommended that certain essential and emergency repair part be maintained in your inventory to minimize any potential downtime.



Find my BAC Rep to order parts, get maintenance tips, and get a free unit inspection: [www.baltimoreaircoil.com/RepFinder](http://www.baltimoreaircoil.com/RepFinder)



## Nexus® Modular Hybrid Cooler

### Basic Recommended Spare Parts

---

**Pump**

**Nozzle/Grommet Kit**

**Mechanical Makeup Valve**

**Solenoid Makeup Valve**

**Solenoid Drain Valve**

**UV Bulb for UV System** (if equipped)

**EC Fan System** (for critical applications)



Scan to locate  
your local BAC  
Representative